BOUND/STUCK LOCKING TEETH ON THE TILT MECHANISM

The locking discs are stuck, but this has an easy remedy, this happens from time to time to new machines when they are in storage. I have done this myself, will just need a rubber mallet/soft blow.

- Remove the Tilt handle and the silver washer disc complete
- With a rubber mallet, or soft blow, tap on the front of the locking disc, while rocking the machine back and forth.



- There is a spring behind the locking desk, does not have a lot of tension, but tapping this piece and rocking the machine will help release the two ends with teeth.
- Once they have split open, apply some type of grease, can be food grade, so that it does not bind again.